

45-1008

Låsekasse 1241


Locking box 1241



45-1010

Låsekasse Dorma DL502


Locking box Dorma DL502



45-1011

Låsekasse 1216 højre (565)

Locking box 1216 right (565)



45-1012

Låsekasse 1216 venstre (565)

Locking box 1216 left (565)



45-1018

Låsekasse 1222 højre (560)

Locking box 1222 right (560)